



SHEER HORIZONTAL WINDOW SHADING



Mounting
Bracket



Wedge




Nut & Bolt




Extension/Side mount
Bracket



"U" Shim



Hold Down Bracket
(optional)



INSTALLATION INSTRUCTIONS

The Sheer Horizontal Window Shadings represent a design breakthrough in style, efficiency and function. The unique fabric structure and hardware system are designed to provide years of reliable service when properly installed.


Please take a few minutes to read through these instructions before beginning.

BASICS A few simple tools are required:

- Measuring tape
- Carpenters Level
- Power drill or Screwdriver

Additional fasteners other than those sent with your shading may be required depending on the mounting surface. Wallboard and plaster require the use of anchors such as expansion or toggle bolts. Brick, tile or stone need special plugs and drill bits. Remember to always pre-drill holes in wood to avoid splitting.

Step 1. BRACKET INSTALLATION




If the headrail does not sit level, the fabric will not roll up evenly which could damage the edges of the shading fabric. Use shims if necessary to level brackets.

End brackets should be located with centerlines 2" in from each end. Depending on the width of the shading, additional brackets may be necessary evenly spaced between the two end brackets.

For Shade widths of:	Use this # of Brackets
Up to 40"	2
>40" - 72"	3
>72" - 84"	4
>84" - 114"	5

Inside Mount




5/8" minimum for shallow mount
3 3/16" minimum for flush inside mount


Use shims if necessary to ensure that the headrail is mounted level (included).

Fully Recessed Inside Mount

Low light gap wedges can be used to reduce the top light gap when the shade is mounted fully recessed. The wedge is placed between the mounting surface and the bracket with the tabs on the wedge facing down and the thick end of the wedge toward the back of the bracket.




Outside Mount



3/4" minimum surface


Extension Brackets (optional)

Optional Extension Brackets are used to project the back of the shading up to 2 1/2" from the mounting surface. Attach the Standard Mounting Bracket to the Extension



Side Mount (optional)


Measure from window sill up to desired mounting position on each side of the window frame. Mark position. Mount Side Mount Brackets on each side of window frame as shown. Make sure to confirm that headrail will sit perfectly level. Once Side Mount Brackets are installed and properly positioned, attach the Standard Mounting Brackets using the nuts and bolts provided.




Position screw in center of slot so you can adjust position of bracket as

Step 2. HANGING THE SHADE


Before installing the shading, it is important to check the position of the bump stops inside the headrail. there are two stops which prevent the bottom rail from travelling too far into the headrail. These bump stops need to be at the ends of the headrail, butting up to the endcap. This will prevent the bottom rail from stacking unevenly in the headrail.



Install Headrail



To remove the shading, partially lower the shading and insert a flat head screwdriver as shown. Twist the screwdriver until the headrail disengages from the bracket.



Step 3. CHILD SAFETY

The Consumer Product Safety Commission requires the use of a cord tie down (cord tensioner) on all continuous loop cord systems. The use of such a device is intended to significantly reduce the occurrence of infant or small child strangulation injuries or deaths resulting from the looped pull cords on various window treatment products.

The Cord Tensioner is installed on the Lift Cord before packaging. The Tensioning device should be mounted in the proper position to pull the cord taut in order to reduce the possibility of injury.

Cord Tensioner Installation

Lower the shade and then position the tensioner on the frame or the wall in a way that will not interfere with the operation of the shade.

The control cord must be taut but still operable. Do not allow for any slack. Do not twist or cross the control cord.

Step 4. OPERATION

To lower the shade pull down on the back cord. When the window shade is completely lowered, pulling the back cord will open the vanes.

Important: Once the vanes are in the open position donot continue pulling the back cord! This will reverse the roll and start raising the shade in the wrong position. Doing this will damage the fabric and void your warranty.


To close the vanes pull the front cord and continue pulling the front cord to raise the shade.

Step 5. HOLD DOWN INSTALLATION (optional)

Use the pin on the hold down bracket to punch out the front hole on the bottom rail end cap.

Mount the hold down to the side or back of the window frame so that the pin lines up with the front hole in the bottom rail end cap with the shade fully lowered and fully open.

Lower the shading and flex the hold down bracket outward so that the pin can be inserted into the hole in the end cap.



CLEANING AND CARE

The Sheer Horizontal Window Shadings are made of sturdy, knitted polyester fabrics and may be feather dusted or vacuumed at a low suction setting. Spots or stains can be rubbed clean with a damp sponge and mild soap. To avoid discoloration of the material, we recommend against the use of chemical cleaners. If necessary the shading may be ultrasonically cleaned by a professional.

All knitted fabrics experience weave variations due to heat, humidity and other room conditions. These variations can result in slight bowing, puckering and dimpling of the Sheer Horizontal material. The possible variations are minor and have been shown through case study not to detract from the beauty of this product.